


PLMa PhyMetrix Loop-powered Moisture Analyzer



Leading edge Nanosensor Technology



more FEATURES

- -110°C to +20°C dewpoint Sensor
- Fast, Accurate and Repeatable
- Small & Lightweight
- State-of-the-art electronics & software
- 316 Stainless Steel & PTFE wetted parts
- NIST calibrations
- Stainless Steel IP68 housing
- Protection from reversed polarity
- Robust Industrial M12 connector, IP68 protection
- 3/4"-16 process interface threads with Viton O-ring
- Interfaces to a variety of panel meters
- Molded IP67 cables available for harsh environment
- Units of measure °C & °F dewpoint, ppmV, ppmW, $\mu\text{B H}_2\text{O}$ vapor pressure, grams of $\text{H}_2\text{O} / \text{m}^3$, Lbs $\text{H}_2\text{O} / 10^6$ standard cubic feet in Natural Gas.

APPLICATIONS

- Petrochemical
- Industrial Gases
- Natural Gas
- Power Generation
- Furnace Gas / Heat Treating
- Air Dryers
- Pharmaceutical
- Aerospace
- Medical



PhyMetrix, Inc.
Moisture Measurement
Innovation at work

- ◆ Test
- ◆ Measure
- ◆ Calibrate
- ◆ Quick
- ◆ Reproducible
- ◆ NIST Traceable


Proudly Designed, Developed and Manufactured in the USA



PLMa PhyMetrix Loop-powered Moisture Analyzer



Mechanical



PLMa Technical Specifications

Moisture Sensor	Range: -110°C to +20°C dewpoint (-166°F to +68°F dewpoint) Accuracy: ±2°C temperature corrected Response time: 95% of step change in 3 min.	Repeatability: 0.8°C Sample flow: >1 LPM
Temperature Sensor	Range: -40°C to +70°C Accuracy: ±2°C	
Ergonomics	Easy and quick installation, no tools required.	
Electrical	5VDC to 28VDC two wire loop operation 4mA to 20mA Housing isolated from 4-20mA Loop Measurement resolution of moisture sensor: 1pF resulting in less than 0.01 °C 5 pin M12 industrial connector IP68 when mating connector fully engaged Mating connectors with molded cables approved for Hazardous Location use available Two conductor cable min. 24AWG (for total cable length >1 mile min. 20AWG) To meet CE requirements cable must be shielded. Built-in digital I/O for controlling relays Optional 2 wire RS-422/485	
Mechanical	All 316 Stainless Steel and PTFE wetted parts for fast response time. Enclosure all stainless steel construction IP67 protection when installed Dimensions (overall) including connector- L: 3.25" (82.6mm) Dia: 1.62" (41.3mm), flats for 1.5" wrench. process threads 3/4"-16 and 14mm x 1.25mm, optionally additional 1/4"NPT can install with either threads Weight Total: 6 oz (0.17 Kg) Pressure: 5000 PSIA (345 Bar)	
Temperature Range	PLMa Analyzer: -20°C to +60°C	Electronics: -40°C to +85°C Moisture Sensor: -20°C to +60°C
Miscellaneous Features	NIST traceable calibrations Units of measure: °C & °F dewpoint, ppmV, ppmW, µB H ₂ O vapor pressure, grams of H ₂ O / m ³ and Lbs H ₂ O /10 ⁶ standard cubic feet in Natural Gas. Digital & Analog: Two Wire 4/20mA loop with HART® Transmitter stores all HART setup Optional Modbus: 2 wire RS-485 ASCII or RTU	

ORDERING INFORMATION	Part Number
PhyMetrix Loop-powered Moisture Analyzer Model: PLaMa Included Accessories: M12 mating Connector with molded 10 feet (3 meter) cable	PLMa
Solid Sensor Shield	suffix -S
Modbus RS-485 option specify ASCII or RTU	suffix -M
Intrinsically Safe ATEX option	suffix -I

Represented by: